


EMC Technical Seminar



All statements, specifications, properties, technical information, and recommendations herein are based on tests; however, the accuracy and completeness are not guaranteed and are subject to change without notice due to product improvement and specification change. This statement is made in lieu of all warranties, expressed or implied, including the implied warranties of marketability, and fitness for purpose. KITAGAWA INDUSTRIES America, Inc. obligation under this warranty shall be limited to replacement of product that proves to be defective. Prior to use, the user shall determine the suitability of the product for its intended use, and the user assumes all risk and liability whatsoever in connection therewith. KITAGAWA INDUSTRIES America, Inc. shall have no liability for any injury, loss, or damage arising out of the use of or the inability to use the products. No statement or recommendation contained herein shall have any force or effect unless in an agreement signed by officers of seller and manufacturer.

Please contact the sales department at KITAGAWA INDUSTRIES America, Inc. for the use of our products prior to selecting the parts for your application.




© Copyright 2019 KITAGAWA INDUSTRIES America, Inc. All Rights Reserved.
Please note that KITAGAWA INDUSTRIES America, Inc. Logo, and other marks are subject of trade marks or registered trade marks of KITAGAWA INDUSTRIES America, Inc. or an affiliate company thereof. KITAGAWA INDUSTRIES America, Inc. reserves other intellectual property rights and nothing herein provides a license under any KITAGAWA INDUSTRIES America, Inc. or any third party intellectual property rights.

Rev 7 – 07182023
G2024-002E

Contents


1. Fundamentals of EMC
- 2. Shielding Techniques and Components**
3. Grounding Techniques and Components
4. Filtering Techniques with Ferrite Cores

Shielding with Low Impedance Material




Radiation of Electromagnetic Waves

- Openings of enclosure
- Cables
- PCB




Reduce radiation by **Shielding**



Shielding helps prevent electromagnetic waves from exiting or entering the enclosure.

Aperture size affects Shielding Effectiveness

Shielding Effectiveness Comparison



	Length (mm)	height (mm)	size (cm ²)			length (mm)	height (mm)	size (cm ²)
S1H	34.0	2.0	0.7		S8H	17.0	2.0	0.3
S11H	34.0	10.0	3.4		S1H	34.0	2.0	0.7
S12H	34.0	20.0	6.8		S9H	50.0	2.0	1.0
S13H	34.0	34.0	11.6		S10H	50.0	2.0	1.5



The maximum dimension has more influence on shielding effectiveness.

Aperture size affects Shielding Effectiveness

Test box:


1. Aluminum case
2. Dimensions: W250 × D180 × H70 (mm)
3. Surface treatment: alumite (non-conductive)

Cutout (5cm × 1cm)





Noise emission in vertical polarization **without a lid**


Aperture size affects Shielding Effectiveness



No significant improvement



Aperture size affects Shielding Effectiveness




Shielding effect of a slit


$$SE(dB) = 20 \text{Log} \left(\frac{\lambda}{2L} \right) \left[\begin{array}{l} \lambda: \text{Wave length (m)} \\ L: \text{largest opening measurement (m)} \end{array} \right]$$

Sealing Slits on Enclosures with Shielding Gaskets



Non-conductive coating removed




Using Gaskets (entire slit)



Using Gaskets (screw positions changed)




Due to repelling force of the gasket, it does not attach well to the lid and can potentially warp and create gaps around the screws.




Recommended Shielding Design


Bad: overall opening is large




Good: overall opening is small



Bad: Non-conductive paint forms a long slit



Good: paint removed, gasket used




Slit should be less than 1/10 of the wavelength

$$\lambda(m) = 300 / f(MHz)$$




In this example of a desktop computer, one could assume that the noise would leak from the blue areas, as there are many holes for the noise to escape from.



However, the areas in red would be the real points of concern.



Taking a closer look by removing the side wall, we can see that contact points were built in, with a small pitch between each point, to ensure the length is no over $1/10^{\text{th}}$ the distance of the wave length.





Same care was taken when designing the face plate for the I/O area and the small fingers, ensuring there is a contact and frame ground.




If noise is still leaking, it would most likely be from these two points, where such care was not taken in the design.

Cable Shielding



Cable Shielding Test



Noise Emission comparison among different grounding methods

- Shielded but not ground
- Shielded and ground to noise source side only
- Shielded and ground to load side only
- Shielded and ground to both sides with grounding wires
- Shielded and ground to both sides with grounding clamps

Site setup 150kHz-30MHz





Site setup 30MHz-300MHz





※ Tested by CISPR25 Class3 method
(for over 30MHz, measured with horizontal polarization only)

Cable Shielding Effectiveness: 30MHz ~ 1000MHz

■ No shielding





■ Shielded but not ground





Cable Shielding Effectiveness: 30MHz ~ 1000MHz

Shielded and ground to noise source side only



Ground with 360° clamp
Noise source side



Shielded and ground to load side only





Ground with 360° clamp
Load side

Cable Shielding Effectiveness: 30MHz ~ 1000MHz

Shielded and ground to both sides with grounding wires





Shielded and ground to both sides with grounding clamps



Cable Shielding Effectiveness: 30MHz ~ 1000MHz

■ Two shields ground at either end and connected with wire



Ground with 360° clamps with center break connected with a wire

Plastic Cable Grounding Example:

- Grounds and fixes cables at the same time
- Does not damage cables (compared to metal clamps)

Cable grounding clamps





Screw-mount





Snap-mount

Cable Shielding Effectiveness: 150kHz ~ 30MHz



■ No shielding





■ Shielded & ground on both sides



■ Shielded & ground on **noise source side only**




■ Shielded & ground on **load side only**





Ground to Noise Source Side

■ High Frequency (30MHz ~ 1000MHz)



■ Low Frequency (150kHz ~ 30MHz)




Ground with 360° clamp
Noise source side

Why did grounding only on the noise source side of the cable work for low frequency test?



Wavelength vs Cable Length

Ground with 360° clamp (noise source side)


Relationship between the cable length (D) to the problem frequency's wavelength (λ) directly affects the cable shield's effectiveness.



If $D > \lambda$, shielding effectiveness is poor





If $D < \lambda$, shielding effectiveness is GOOD



On-Board Grounding Clips for Shield Cans

Shield cans prevent:

- EM radiation from the IC
- Susceptibility to EM emissions from other sources






Board-level grounding clips



Features




- ◆ Same effect as soldering
- ◆ Easier maintenance, including mounting check
- ◆ Maximize use of PCB space
- ◆ Small footprint

Options for Attaching Shielding Can

Shield Can + Mounting Options	Image	Advantages	Disadvantages
Shield Can + Shield Can Clip		<ol style="list-style-type: none"> 1) Easy inspection and maintenance 2) Low manufacturing and parts costs 3) Effective use of available space on PCB (less dead space) 4) No added tooling cost 	<ol style="list-style-type: none"> 1) May increase number of pieces required
Shield Can + Perimeter Solder		<ol style="list-style-type: none"> 1) Fewer parts to track 2) Best shielding performance if can is 100% perimeter soldered 	<ol style="list-style-type: none"> 1) Requires special coating on shield can for soldering process 2) Solder must be broken for maintenance, high potential for board/ component damage 3) Can take long time for service and maintenance
Shield Can + Fence		<ol style="list-style-type: none"> 1) Easy maintenance and inspection 	<ol style="list-style-type: none"> 1) Two tooling charges 2) Poor use of space 3) Difficult to rework 4) Difficult to reduce product height

Shielding Effectiveness Comparison


- Compare solder vs. shield can clips (OGCP) between 500MHz ~ 2.5 GHz
- 4 pts of solder vs 4 pts of OGCP yield similar shielding effectiveness
- Perimeter solder vs 8 pts OGCP yield similar results



When connected at same contact point, soldering and OGCP have the same shielding effect.

Shielding Effectiveness at 16GHz

$\lambda = 18.75\text{mm @16GHz}$




Recommended distance between grounding points is less than 1/10 wavelength (λ).

Reflow Process

- Clips are designed to be self-aligning.
- Even if the placement is off-center or tilted, the clips self-correct onto the solder pad during the reflow process.




Before reflow



After reflow




Before reflow




After reflow

Shielding Can Clip Design




Designed with a wide opening on top to allow the shield cans to installed correctly without crushing or damaging the clip

Automated Shield Can Installation



*wide nozzle to accommodate the shield can's surface



Fuji Machine Mfg. Co., Ltd.
Pick-and-Place machine